


WRC



■ WIRED CONTROLLER

Dear Customer,

Thank you for wanting to learn about a product Aermec. This product is the result of many years of experience and in-depth engineering research, and it is built using top quality materials and advanced technologies.

The manual you are about to read is meant to present the product and help you select the unit that best meets the needs of your system.

However, please note that for a more accurate selection, you can also use the Magellano selection program, available on our website.

Aermec, always attentive to the continuous changes in the market and its regulations, reserves the right to make all the changes deemed necessary for improving the product, including technical data.

Thank you again.

Aermec S.p.A.

CERTIFICATIONS

COMPANY CERTIFICATIONS



SAFETY CERTIFICATIONS



This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled disposal of Waste Electrical and Electronic Equipment (WEEE), please return the device using appropriate collection systems, or contact the retailer where the product was purchased. Please contact your local authority for further details. Illegal dumping of the product by the user entails the application of administrative sanctions provided by law.



In accordance with Italian Legislative Decree 116 / 2020, the machine's packaging is marked; for unmarked packaging parts, the composition is as follows: **Expanded polystyrene - PS 6**

All specifications are subject to change without prior notice. Although every effort has been made to ensure accuracy, Aer-mec shall not be held liable for any errors or omissions.

TABLE OF CONTENTS

1	Electrical device warnings	6
1.1	Warning and hazard terms	6
1.2	GENERAL WARNINGS	6
1.3	WARNINGS FOR THE USER	7
1.4	WARNINGS FOR THE INSTALLER	7
2	Operation notices	9
3	Wired Controller	10
3.1	User interface (display)	11
4	Buttons	13
4.1	User interface (buttons)	13
5	Installation and start-up	14
5.1	Installation of the Wired Controller	14
5.2	Commissioning	20
6	Functions available from wired panel	28
6.1	Switching the indoor unit ON and OFF	28
6.2	Select the operating mode for the indoor unit	29
6.3	Operating logic for AUTO Mode	30
6.4	Modifying the operating temperature	30
6.5	Modifying fan speed	31
6.6	Timer Setting	32
6.7	Set delivery fin (swing)	35
6.8	Quiet Function Setting	36
6.9	Activating/Deactivating the night-time comfort function	37
6.10	Set the display function on the indoor unit	38
6.11	Set the ENERGY SAVING function active on indoor unit	39
6.12	Set indoor unit FILTER CLEANING alarm	40
6.13	X-fan Setting	41
6.14	Set the ANTIFREEZE function on indoor unit	42
6.15	Shielding status	42
6.16	Set key lock on wired panel	42
6.17	Inquiry of Indoor Temperature with one button	43
7	Display operating errors or system messages	44
8	Table of display error codes for MV unit	44
8.1	Table of error codes for outdoor unit	44
8.2	Table of error codes for indoor unit	45
8.3	Table of debugging codes	45
8.4	Table of status codes	46

1 ELECTRICAL DEVICE WARNINGS

1.1 WARNING AND HAZARD TERMS

Before proceeding with any assessment or operation on the unit, carefully read this manual and all of its notes marked with the following symbols, which indicate the various levels of hazard or situations that are potentially hazardous to prevent malfunctioning or physical damage to property or personal injury:

WARNING



Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION



Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

MANDATORY



This indicates a mandatory action that, if not carried out, could cause death or serious injuries.

PROHIBITION



Indicates a prohibited action which, if not avoided, could result in death or serious injury.

NOTICE



IMPORTANT additional information on how to use the product

1.2 GENERAL WARNINGS

CAUTION



Failure to observe these instructions can cause damages to property or people's injuries, which may be serious depending on the circumstances.

NOTICE



Read carefully these general safety precautions before installing the air conditioning devices and ensure that the installation is performed correctly.



Aermec S.p.A. will in no case be liable for any damages to property and/or persons caused by improper operations such as: incorrect installations, debugging or maintenance not carried out, non-compliance with the installation regulations foreseen in the country where the device will be installed or non-compliance with the rules contained in this manual.



Refer to the national regulations for the installation: the device must be installed in compliance with national plant engineering rules.

1.3 WARNINGS FOR THE USER

CAUTION



To prevent electric shock or fire accidents:

1. Do not operate the air conditioner with wet hands.
2. Do not disassemble the device or remove its internal parts.
3. Do not modify or repair the air conditioner by yourself.
4. Do not move or re-install the device by yourself.
5. Do not use flammable materials near the device.



To clean the device, do not use organic solvents, such as paint thinners. Possible result: damages, electric shock or fire accidents.

NOTICE



It is not recommended for persons (including children) with limited physical, sensorial or mental abilities, or operators without experience and knowledge, to use the machine unless in the presence of a person responsible for their safety capable of monitoring them and of providing adequate instructions for use. Do not allow children to play with the appliance.



All illustrations and information contained in this manual are purely indicative; for the actual command of the device functions, refer to the controller display (if fitted).



In order to improve the product, we reserve the right to modify or revise this document without prior notice; therefore remember to periodically verify the presence of new versions.

1.4 WARNINGS FOR THE INSTALLER

CAUTION



Improper installation or assembly of the device could cause electrocution, short-circuits, leaks and fires.



Ensure that the electrical power supply complies with the parameters included in this manual. A power supply that is different from the recommended one can cause damage.



Ensure that all connections are performed according to the instructions in this manual. Incorrect connections could cause communication malfunctioning.



Ensure to be able to use the correct communication ports, otherwise the connection may not work properly.



The connected communication line must be protected with electrical tape to prevent oxidation and short-circuits.



Do not install the device in a location where it could be affected by inflammable gas leaks or deposits of materials which are inflammable, explosive, poisonous, corrosive or hazardous substances. Install the device in a place with minimal levels of dust, fumes, air humidity and corrosive agents.

MANDATORY



The electric connections and installation of the device must only be performed by individuals with the technical-professional requisites for installation, transformation, expansion and maintenance of the systems and able to check the same for safety and functionality purposes. In this manual they will be generically referred to as "Staff with specific technical skill".



Use exclusively optional devices and spare parts approved by Aermec S.p.A..

PROHIBITION



This device cannot be used on its own. Also refer to the user manuals of the outdoor/indoor unit.

2 OPERATION NOTICES

MANDATORY



The power supply for all indoor units must be unified.



When the system mode priority is the master-slave mode, in one system network, you must set one indoor unit as the master indoor unit, other indoor units are slave indoor units.

PROHIBITION



Never install the wired controller in the moist circumstance or expose it directly under the sunlight.



Never beat, throw, and frequently disassemble the wired controller and the wireless remote controller.



Never operate the wired controller and the wireless remote controller with wet hands.

NOTICE



When the system mode priority is the master-slave mode, the operation mode of the system is basing on that of the master indoor unit. The master indoor unit can be set to any mode (including auto mode), while the slave indoor unit can't set to the mode that conflicts with the system mode.



When an operation mode is set, the indoor unit can be set to any mode (excluding auto mode). The indoor unit will automatically switch to the system mode, when the operation mode of the indoor unit conflicts with the system operation mode.



System mode priority defaults to master-slave mode and only certain units have other system mode priorities.



When two wired controllers control one (or more) indoor unit(s), the address of wired controller should be different.



If a function is not available for the indoor unit, the remote control cannot set the function.




Please read the manual carefully before using and installing this product.

3 WIRED CONTROLLER


The WRC wired panel allows display and rapid setting of the machine's operating parameters. The card stores all the default settings and any modifications. After the absence of voltage for any period of time, the unit is able to start up again automatically, maintaining the original settings.

The user interface comprises an LCD display with icons used to display information and available functions about the units; the user may interact with the panel using the function keys located in the lower part of the panel itself.

Wired Controller



3.1 USER INTERFACE (DISPLAY)



The following table indicates which functions match the various icons available on the wired panel's LCD display:

Number	Description
1	Function not available
2	Function not available
3	Function not available
4	Indicates that AUTOMATIC mode is active (only available on the MASTER unit)
5	Indicates that COOLING mode is active (only available if the MASTER unit is set with a compatible mode): COOLING, DEHUMIDIFICATION)
6	Indicates that DEHUMIDIFICATION mode is active (only available if the MASTER unit is set with a compatible mode): COOLING, DEHUMIDIFICATION)
7	Fan mode
8	Indicates that HEATING mode is active (only available if the MASTER unit is set with the same mode):
9	Function not available
10	Function not available
11	Indicates the status of the SWING (vertical) function
12	Function not available
13	Indicates the current fan setting
14	These icons are displayed when setting operating parameters; they indicate the maximum (when setting the heat limit) or minimum (when setting the cool limit) values
15	During normal unit operation, the temperature setting in use is displayed

Number	Description
16	Indicates the unit of measure used to indicate the temperature settings
17	This group of icons depicts the functions and information associated with the system time or the options associated with the unit ON/OFF timer
18	Indicates the SLEEP function is active
19	Function not available
20	Indicates that the QUIET quiet operation was activated
21	If fitted, it indicates that wired panel backlighting is active
22	Function not available
23	Indicates that the antifreeze function was activated
24	Function not available
25	Indicates that the key lock function is active on the panel Indicates that all the buttons of the remote control are locked
26	Indicates that energy saving mode is active on the indoor unit connected
27	Indicates that the wired panel is a slave (i.e. two wired panels are connected to the indoor unit: one master and one slave)
28	Function not available
29	Indicates that the outdoor unit is operating in "safe" mode
30	This icon appears in order to indicate that the filter on the indoor unit must be cleaned
31	Function not available
32	Indicates that the X-FAN function is active on the unit (this function dries the coil in cool or dehumidification mode)
33	Function not available
34	Indicates that the outdoor unit is currently defrosting
35	This icon indicates that the panel was disabled by a remote controller (zone control, mains control) VRF Debugger
36	This icon indicates that the wired panel controls several indoor units (a group)
37	Indicates that the Indoor unit is resuming the settings stored in memory (this event occurs after a black-out)
38	Indicates that the indoor unit connected to the panel is the system MASTER


NOTICE



When wired controller is connected with different indoor units, some functions will be different.

4 BUTTONS

4.1 USER INTERFACE (BUTTONS)



Number	Description
1	Selects or Cancels desired function
2	Sets night-time comfort mode SLEEP
3	Activates or de-activates certain extra functions (for example the QUIET, X-FAN, SAVE, CLEAN modes...)
4	Sets data for unit timers
5	Decrease the value of the active function: • Temperature • Time • Timer Pass to the previous data
6	Sets the fan speed
7	Sets the operating mode
8	Sets automatic delivery fin oscillation (on units where this is envisaged)
9	Switches indoor unit ON/OFF
10	Increase the value of the active function: • Temperature • Time • Timer Pass to the previous data
5+10	Press the buttons ▼ and ▲ at the same time for 5 seconds to enable or disable the button lock function

5 INSTALLATION AND START-UP

MANDATORY



MV systems must have a master only one) for correct management of the operating modes. For the setting procedure, refer to the specific section.

Fig. 5.1.1: Dimensions of Wired Controller





Fig. 5.1.2: Parts and Components of Wired Controller




N.	1	2	3	4
Name	Wired Controller	Self-tapping screw ST3.9x25 MA	Screw M4x25	Soleplate of the Wired Controller
Quantity	1	3	2	1

5.1 INSTALLATION OF THE WIRED CONTROLLER

5.1.1 Requirements for model selection of communication wire

Fig. 4.3: Length of communication wire



$$L = L01 + L02 + L1 + L2 + \dots + L(n-1) \quad (n \leq 16)$$

Cable type	Max lenght	Size	Standard	Note
Standard 2-pole cable with PVC sheath (60227 IEC 52 / 60227 IEC 53)	$L \leq 250$ m	from 2 x 0,75 to 2 x 1,25 mm ²	IEC 60227-5:2007	1. Total length of communication line can't exceed 250m. 2. The cord shall be Circular cord (the cores shall be twisted together). 3. If unit is installed in places with intense magnetic field or strong interference, it is necessary to use shielded wire.

NOTICE



If the unit is installed in a location with intense electromagnetic interference, the wired panel communication line must use a screened twisted pair.



The wired panel communication line materials must be chosen strictly in accordance with this instruction manual.

5.1.2 Requirements for installation


1. It is not allowed to install the wired controller in the wet place.
2. It is not allowed to install the wired controller in the place with direct sunlight.
3. The wired control panel must not be installed near heat sources or places where it may come into contact with water.
4. It is not allowed to install the wired controller outdoor.

5.1.3 Requirements for wired connection

Network connecting methods between wired controller and indoor unit are as below:


1. The wired panel communicates with the Indoor unit through a serial port; it is possible to select several Indoor unit management configurations using the wired panel:
 - A. SINGLE connection, where the unit (or group of units) is managed by a single wired panel;
 - B. DUAL connection, where the unit (or group of units) is managed by two wired panels, one of which is the MASTER and the other is the SLAVE.

Fig. 5.3: one wired controller controls one indoor unit



1. D1 D2
2. H1 H2


Fig. 5.4: two wired controllers control one indoor unit



1. D1 D2
2. H1 H2

2. The second serial connection possibility envisages only one panel (reminder: each individual unit of group of units can be managed by a single panel or by two panels connected to the same Indoor unit in MASTER/SLAVE mode, as indicated in the previous page) for the overall group of units (a group may comprise max. 16 units); this solution allows unique settings for the timer, setpoint and ventilation speed for all the Indoor units in the group.


Fig. 5.5: one wired controller controls multiple MV indoor units simultaneously



1. D1 D2
2. H1 H2

3. The third serial connection possibility envisages two panels (reminder: each individual unit of group of units can be managed by two panels connected to the same Indoor unit in MASTER/SLAVE mode, as indicated in the previous page) for each unit; this solution allows customised settings for the timer, setpoint and ventilation speed for each indoor unit;

Fig. 5.6: two wired controllers control multiple MV indoor units simultaneously



1. D1 D2
2. H1 H2

NOTICE



If the units are installed in a location exposed to electromagnetic interference, shielded twisted pair cables must be used for the communication connections between the units.

Instruction for wire connection:


1. The wiring methods in Fig. 5.3 and Fig. 5.4 can be adopted for the wired panel connecting the MV units, i.e., one or two wired panels can control only one indoor unit, but cannot control multiple indoor units of different systems.
2. When one (or two) wired controller(s) control(s) multiple indoor units simultaneously, the wired controller can connect to any one indoor unit. The total quantity of indoor unit controlled by wired controller can't exceed 16 sets, and the connected indoor unit must be within the same indoor unit's network. Wire controller must set quantity of group control indoor units. Please refer to Parameter Setting "P14".
3. When two wired controllers control one (or more) indoor unit(s), the addresses of those two wired controllers should be different. Please refer to Parameter Setting "P13".
4. The terminal of the wire controller is non-polarized and cannot be connected to strong electric.

NOTICE



Wired controller WRC only supports one (or more) indoor unit(s) controlled by one wired controller.


4. The fourth serial connection possibility envisages a panel (reminder: each individual unit of group of units can be managed by a single panel or by two panels connected to the same Indoor unit in MASTER/SLAVE mode, as indicated in the previous page) for each unit; this solution allows customised settings for the timer, setpoint and ventilation speed for each Indoor unit.



⚠ ATTENTION:

3, 5, 7 ≤ 250m

5. The fifth serial connection option involves either a single panel connected to a group of multiple units, or a panel connected and dedicated to each unit.



⚠ ATTENTION:

3 + 4 ≤ 250m

8, 9 ≤ 250m

5.1.4 Installation

Fig. 5.7: Installation of Wired Controller




Fig. 5.7 shows a simple installation course of wired controller, and the following points should be noted:

1. Before installation, please cut off the power supply of indoor unit, it is not allowed to operate with power supply;
2. Pull out the 2-core twisted pair inside the installation hole in the wall, and thread the wire through the hole in the back of soleplate of wired controller;
3. Stick the soleplate of wired controller on the wall, and use Self-tapping Screw ST3.9×25 MA or screw M4×25 to fix the soleplate with the installation hole of wall;
4. Connect the 2-core twisted pair to wiring terminal H1 and H2, and then tighten the screw;
5. Arrange the wires in the back of panel, and then buckle the panel of wired controller with the soleplate of wired controller.

NOTICE



If the chosen communication line cable size is too large, a layer of cable sheath can be removed to meet installation requirements.




Notes for installing the wired panel It is advised not to install the wired panel where it may come into contact with water or direct sunlight; it is also advised to avoid installation too close to sources of intense heat.



MV systems must have a master only one) for correct management of the operating modes. For the setting procedure, refer to the specific section.

5.1.5 Disassembly

Fig. 5.8: Disassembly of wired controller



5.2 COMMISSIONING

5.2.1 Set a Master unit

Under Off status, long press "MODE" button for 5s to set the corresponding indoor unit of wired controller as master indoor unit.

If the system mode priority is the master-slave mode, "MASTER" icon will be light after finishing setting.

NOTICE



In a system with a master indoor unit, other slave indoor units can be set as master units; in this case the original master unit will become a slave unit.




Only one main indoor unit is allowed in a system. If the system detects the presence of several master units, it will designate the unit with the smallest project number as the master unit.

5.2.2 Display indoor unit operating parameters

This function is used to display a series of operating parameters (each code is associated with the letter "C"); the parameters in this menu may not be modified but only displayed (read only); to read the operating parameters, perform the following operations:


1. Press "FUNCTION" button for 5s to enter the interface of viewing unit parameters. "C000" is displayed in temperature zone.
2. Press the buttons ▼ or ▲ to scroll the operating parameters.
3. Press "ENTER" button to return to last step until exits viewing parameters.



The parameter enquiry list is as following:

Index parameter	Function	Range	Description of operating parameter
C 00	Indoor unit project number	-	This parameter indicates the project number assigned to the Indoor unit to which the wired panel is connected (if the panel is connected to several units, the lesser project number will be displayed). The project number is a value assigned automatically by the system so that each indoor unit can be specifically identified (auto-addressing function); this number is fundamental for identifying the unit through software in order to monitor the system (for more information as regards system monitoring software, refer to www.aermec.com)
C 01	System error monitor	1-255	This parameter is used to scroll all the project numbers (and consequently all the units in the system) to search for any errors; to scroll the list of units, perform the following operations: (1) Select the operating parameter "C01"; (2) Press the "MODE" button to enter the list of indoor units (after entering this list, the setpoint area will display any alarm codes while the timer zone will display the project number for the indoor unit in question; if the Indoor unit currently displayed is the system master, the "MASTER" icon will be displayed); (3) Press the arrow buttons to scroll the indoor units; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters WARNING: if an error occurs in one or more indoor units when assigning the project number, in place of this number (in the timer zone) error code C5 will be displayed; in this case, the system initialisation procedure must be repeated (for more information as regards system initialising, contact the area technical assistance service)
C 03	Total number of indoor units in the system	1-100	This parameter indicates (in the timer zone) the total number of indoor units connected to the system
C 06	Display the operating priority of these indoor units	00: normal operation 01: priority operation	This parameter displays the priority assigned to each Indoor unit; priority means which units are used in case the system detects power drops, thereby making it possible to select which indoor units should be given priority, as required, over other units (in this parameter, this priority has a value of 01 while the standard priority has a value of 00); to scroll the priorities assigned to each unit, perform the following operations: (1) Select the operating parameter "C06"; (2) Press the "MODE" button to enter the list of indoor units (after entering this list, the setpoint area will display the project number for the indoor unit in question while the timer zone will display the priority setting; if the Indoor unit currently displayed is the system master, the "MASTER" icon will be displayed); (3) Press the arrow buttons to scroll the indoor units; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters

Index parameter	Function	Range	Description of operating parameter
07	Display the room temperature	-	This parameter is used to display the room temperature read on each indoor unit (in accordance with the specific settings of each individual unit); to display the room temperatures, perform the following operations: (1) Select the operating parameter "C07"; (2) Press the "MODE" button to enter the list of indoor units (after entering this list, the setpoint area will display the number of the unit while the timer zone will display the project number for the indoor unit in question); if the Indoor unit currently displayed is the system master, the "MASTER" icon will be displayed); (3) Press the arrow buttons to scroll the indoor units; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
08	Display the current setting for the filter cleaning alarm	4-416: days	This parameter indicates (in the timer zone) the number of days set as the period after which a message will be displayed requesting removal and cleaning of the air filter on the Indoor unit to which the wired panel is connected
09	Display the address of the wired panel	01, 02	This parameter indicates (in the timer zone) the address assigned to the wired panel (this address is fundamental if two different wired panels are used to manage one or more units, since the two panels must have different addresses)
11	Number of units in the group	1-16	This parameter indicates (in the timer zone) the number of units in any group connected to the wired panel
12	Display external temperature;	-	This parameter indicates (in the timer zone) the temperature of the external air
17	Parameter reserved		
18	Display all project numbers at the same time	1-255	This parameter is used to scroll all project numbers (and consequently all the units in the system) associated with the unit number (in relation to the total number of internal units in the system); to scroll the list of units, perform the following operations: (1) Select the operating parameter "C18"; (2) Press the "MODE" button to enter the list of indoor units (after entering this list, the setpoint area will display the number of the unit while the timer zone will display the project number for the indoor unit in question); if the Indoor unit currently displayed is the system master, the "MASTER" icon will be displayed); (3) Press the arrow buttons to scroll the indoor units; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters ATTENTION: - After displaying parameter C18, all indoor unit wired panels will display (in the timer zone) their specific project numbers, which will remain displayed until this function is closed; - Reminder: it will not be possible to enter this parameter if access is attempted from a slave wired panel (installation with two wired panels connected to the same indoor unit); - reminder: pressing the "ON/OFF" button on any wired panel during this function will immediately finish it; - If, when displaying parameter C18, no operation is performed for more than 20 seconds, the function is automatically exited.
20	Parameter reserved		
23	Version inquiry	-	Timer zone: program version of the current wired controller



NOTICE

In the parameter display state, the "FAN", "TIMER" and "SWING" buttons are not valid. Press the "ON/OFF" button to return to the home page, not to switch the unit on/off.



Under parameter viewing status, the signal from remote controller is invalid.

5.2.3 Activation of indoor unit operating parameter modification menu

CAUTION



Accidental modification of these parameters may cause malfunctions or block the entire system; reminder: setting or modifying these parameters must ONLY be performed by the technical assistance service or personnel having the necessary technical skills.

This function is used to modify a series of operating parameters (each code is associated with the letter "P"); to set these operating parameters, perform the following operations:

1. Long press "FUNCTION" button for 5s and the temperature zone displays "C 00"; long press "FUNCTION" button for another 5s to enter the interface of setting wired controller parameters. "P 00" is displayed in temperature zone.
2. Press ▼ or ▲ to scroll the operating parameters. Press the MODE button to access the parameter setting. At that moment, the parameter value will flash. Press ▼ or ▲ to adjust the parameter value and press ENTER/CANCEL to end the setting.
3. Press the "ENTER/CANCEL" button again to exit the operating parameter display.

The parameter setting list is as following:

LIST OF OPERATING PARAMETERS

Index parameter	Function	Default	Range	Description of operating parameter
P 00	Set the system MASTER unit	00	00: Slave Unit 01: MASTER unit	This parameter is used to set an Indoor unit as the system master; for these systems, the presence of a master unit IS ABSOLUTELY COMPULSORY; inasmuch, one of the indoor units must be set as such; reminder: the master unit is the reference unit for solving mode conflicts; consequently, if the master changes its operating mode, so does the entire system; to set the parameter, proceed as follows: (1) Select the operating parameter "P10"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters ATTENTION: • after setting a master, its wired panel will indicate its master status by means of an icon; • if, after setting a unit as the master, the operation is repeated on another Indoor unit, the master status will be modified, and the system will be updated with the new reference unit
P 11	Enable infra-red remote controls	01	00: NOT enabled 01: enabled	This parameter is used to enable or disable the infra-red remote controls on the system (if envisaged); this parameter can ONLY be set from the panel of the master indoor unit; to set the parameter, proceed as follows: (1) Select the operating parameter "P11"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 13	Set the address of the wired panel	01	01: MASTER panel 02: SLAVE panel	This parameter is used to set the address to be assigned to the wired panel; this parameter is used if two panels are connected to the same machine or the same group in order to set two different addresses; to set the parameter, proceed as follows: (1) Select the operating parameter "P13"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters

Index parameter	Function	Default	Range	Description of operating parameter
P 14	Set the number of units in the group	01	00: test disenabled 01-16: group with ... units	This parameter performs a test on the group (if a group has been created) in order to specify how many indoor units belong to it. This test checks whether the number set in the parameter matches the number of units detected by the system in the group; if this function is disenabled (value 00) and the wired panel manages a group, no alarms will be displayed for any malfunctions in this group; to set the parameter, proceed as follows: (1) Select the operating parameter "P14"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 16	Set unit of measure	00	00: °C 01: °F	This parameter specifies which unit of measure is used to display temperatures; to set the parameter, proceed as follows: (1) Select the operating parameter "P16"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 30	Setting the useful head for the fans of duct type indoor units	05	01-09: Useful head level	There are two kinds of Useful head level: • 5 levels: 03, 04, 05, 06, 07; • 9 levels: 01, 02, 03, 04, 05, 06, 07, 08, 09. The wired panel is compatible with different types of indoor units, and it is equipped with a 1 to 9 useful pressure level selection. When the indoor unit with 5 useful pressure levels receive a level setting lower than 3 from the remote control, the pressure is set to the 3rd level; when it is higher than 7, it is set to the 7th level.
P 31	Parameter not used	---	---	---
P 33	Set type of clock	00	00: countdown 01: Clock	This parameter is used to select which type of clock must be activated on the system; possible modes are: • COUNTDOWN: management of timed actions after a certain number of hours (for more information about this mode, refer to page "6.6.1 Modifying the programmed ON/OFF timer - COUNTDOWN mode on page 32" in this manual); • STANDARD CLOCK: management of timed operations using the system clock (this clock must be updated by the user. For more information in this regard, refer to page "6.6.2 Set system time (only used in CLOCK mode) on page 33" in this manual); To set the parameter, proceed as follows: (1) Select the operating parameter "P33"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 34	Set repetition of time settings	00	00: repetition disenabled 01: repetition enabled	This parameter is used to set (only if parameter P33 is set with the value 01) the repetition of time settings; if the repetition function is disenabled, the time settings will be performed only once and they will have to be set again every day; to set the parameter, proceed as follows: (1) Select the operating parameter "P34"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters

Index parameter	Function	Default	Range	Description of operating parameter
P 37	Cool set for AUTO mode	25°C (77°F)	17°C~30°C (63°F~86°F)	This parameter is used to define a cool setpoint used in AUTO mode (reminder: the auto mode is only available on the master unit); to set the parameter, proceed as follows: (1) Select the operating parameter "P37"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 38	Heat set for AUTO mode	20°C (68°F)	16°C~29°C (61°F~84°F)	This parameter is used to define a heat setpoint used in AUTO mode (reminder: the auto mode is only available on the master unit); to set the parameter, proceed as follows: (1) Select the operating parameter "P38"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 43	Set indoor unit priority	00	00: normal priority 01: high priority	This parameter is used to select the priority to be assigned to the Indoor unit connected to the wired panel; this priority, if the unit detects power drops, makes it possible to exclude indoor units having normal priority in favour of those with high priority; to set the parameter, proceed as follows: (1) Select the operating parameter "P43"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 46	Enable filter cleaning alarm	00	00: filter cleaning alarm disabled 01: filter cleaning alarm enabled	This parameter is used to enable or disable the filter cleaning alarm (set using the specific function "6.12 Set indoor unit FILTER CLEANING alarm on page 40" in this manual on page); to set the parameter, proceed as follows: (1) Select the operating parameter "P46"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 49	Set delivery fin standard opening	01	01: 25° opening 02: 30° opening 03: 35° opening	This parameter is used to set the standard opening (i.e. the position taken by the delivery fin once the unit is switched on for heat or cool) of the indoor units fitted with motor-driven delivery fins (inasmuch, canalised units are excluded); to set the parameter, proceed as follows: (1) Select the operating parameter "P49"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the required value; (4) Press the "ENTER/CANCEL" button to return to the list of operating parameters
P 50	Parameter reserved	18°C	---	---
P 51	Parameter reserved	22°C	---	---
P 54	Parameter reserved	00	---	---
P 74	Parameter reserved	01	---	---
P 75	Ventilation setting with thermostat off	00	00: low speed 01: turned off	Valid only for tray units
P 76	Parameter reserved	00	---	---
P 78	Parameter reserved	00	---	---
P 82	Set time format	00	---	This parameter allows you to set the time format (12 - 24h)

NOTICE



In the parameter setting state, the "FAN", "TIMER" and "SWING" buttons are not valid. Press the "ON/OFF" button to return to the home page, not to switch the unit on/off.



Under parameter setting status, the signal from remote controller is invalid.

5.2.4 Activation of the menu to modify the ADVANCED OPERATING PARAMETERS of the indoor unit

Press the FUNCTION button for at least 5 seconds, after which the temperature setting will be replaced by an indication of the operating parameter currently displayed (from C00 up to C23; for more information about the operating parameters sequence and the data displayed, refer to the table provided below).

Press the MODE key 3 times in succession (with intervals of less than 1 second).

Press the FUNCTION again for at least 5 seconds, after which Parameter C00 will be replaced by the first modifiable parameter identified by the code P00 (sequence from P00 to P82); for more information about the operating parameters sequence and the data displayed, refer to the table provided below).

Press the buttons ▼ or ▲ to scroll the operating parameters.

Press the MODE key to access the operating parameter to be modified; then the value of the operating parameter flashes and it can be modified by using the keys ▼ or ▲.

Press the "ENTER/CANCEL" button again to exit the operating parameter display.

Index parameter	Function	Default	Range	Description of operating parameter
P 20	Setting of the temperature sensor to be used on the indoor unit	03	01: Intake temperature sensor 02: Temperature sensor pm external panel flush 03: Intake temperature sensor for cold mode, dehumidification and ventilation only, sensor on flush panel for hot mode 04: Sensor on flush panel for cold mode, dehumidification and ventilation only, intake temperature sensor for heating mode	In case of master and slave control panels and should you wish to use the temperature sensor on the flush panel, by default the sensor of the master flush panel is selected and used. Note: (1) In automatic mode, the room temperature sensor settings are not valid for a common indoor unit however the set value will still be stored. (2) The ambient temperature sensor located on the control panel when the reference indoor unit is a heat recovery unit cannot be selected. The intake temperature sensor will be selected by default.
P60	Air Temperature Probe Selection	00	00: INTAKE air temperature probe - RT1 01: FLOW air temperature probe - RT3	This parameter allows you to select which air probe to use for temperature management: (1) Select the operating parameter "P60"; (2) Press the "MODE" button to enter the parameter modify mode; (3) Press the arrow buttons to set the value 01; (4) Press the "SWING/ENTER" button to return to the list of operating parameters. P60 = 00: The unit manages temperature regulation using the INTAKE air temperature probe (RT1). In this configuration, using parameter P20, it is also possible to select whether control should take place via the probe installed on the machine or via the probe integrated into the wired control panel. P60 = 01: The unit manages temperature regulation using the FLOW air temperature probe (RT3). Note: Parameter P20 remains visible in the configuration menu, but any changes made will not have any effect on operation of the unit.
P 80	Temperature display	00	00: temperature setting display 01: room temperature display	

6 FUNCTIONS AVAILABLE FROM WIRED PANEL

6.1 SWITCHING THE INDOOR UNIT ON AND OFF

The Indoor unit (or group of indoor units) managed by the wired panel is/are turned on and off using the ON/OFF button; every time it is pressed thereafter will switch the connect Indoor unit ON or OFF. The interfaces of "ON/OFF" status are shown in Fig. 6.1 and 6.2.

Fig. 6.1: Interface of ON status





Fig. 6.2 Interface of OFF status



6.2 SELECT THE OPERATING MODE FOR THE INDOOR UNIT

The various operating modes have different features and ranges:


- **AUTOMATIC mode (AUTO)**: in this mode, the remote control does not display any set-point value and the fans speed is set to AUTO;
- **COOLING mode (COOL)**: in this mode the user must set the operating set-point and a fan speed; if the room temperature is higher than the set value, which can be seen on the display, the air conditioner will continue to cool the air until the room temperature will reach the setpoint value;
- **DEHUMIDIFICATION mode (DRY)**: in this mode the user must set the operating set-point but not the fan speed (which remains fixed at minimum); if the room temperature is higher than the set value, which can be seen on the display, the air conditioner will continue to dehumidify the air until the room temperature will reach the setpoint value;
- **VENTILATION mode (FAN)**: in this mode the user must set only the fan speed. This mode provides no heating or cooling but only uses the internal fan to ventilate the space;
- **HEATING mode (HEAT)**: in this mode the user must set the operating set-point and a fan speed; if the room temperature is lower than the set value, which can be seen on the display, the air conditioner will continue to heat the air until the room temperature will reach the setpoint value.

NOTICE



AUTO mode is ONLY available on the Indoor unit set as MASTER.

Sets the operating mode



NOTICE



The available modes are different for different models, the wired controller will automatically select mode setting range according to the model of indoor unit.




Only the main indoor unit in master-slave mode can set the automatic mode.



In Automatic mode, if the indoor unit operates in Cooling, the icons “△” and “❄” come ON; if the indoor unit operates in Heating, the icons “△” and “☀” come ON.

6.3 OPERATING LOGIC FOR AUTO MODE



If $TEMP \leq 22^{\circ}\text{C}$ Heat Mode will be activated with a setpoint of 20°C (setpoint can be chosen from parameter P38)

If $22^{\circ}\text{C} < TEMP < 26^{\circ}\text{C}$ the last active mode will be activated (but if this is the initial start-up, then Ventilation Only mode will be selected)

If $TEMP \geq 26^{\circ}\text{C}$ Cool Mode will be activated with a setpoint of 26°C (setpoint can be chosen from parameter P37)

NOTICE




In the case of systems with multiple internal units, this function must be set on the Master unit; if set on the Slave units, it will have no effect.

6.4 MODIFYING THE OPERATING TEMPERATURE

To modify the operating temperature, regardless of the operating mode (except for Ventilation Only which does not use the operating setting), simply press the buttons ∇ or $\blacktriangle$ respectively to decrease or increase the operating setting by 1°C .

Set the operating temperature



In Cooling, Ventilation and Heating mode the temperature range is $16^{\circ}\text{C} \sim 30^{\circ}\text{C}$.

In Dehumidification mode, the temperature setting range is 12°C or $16^{\circ}\text{C} \sim 30^{\circ}\text{C}$. When the temperature is 16°C , press " ∇ " repeatedly twice to lower the temperature to 12°C (when the power saving function is enabled, the temperature in Dehumidification mode cannot be adjusted to 12°C and the temperature range is: "lowest temperature in energy saving mode" $\sim 30^{\circ}\text{C}$).

NOTICE




In Auto mode or with the Antifreeze function enabled, the set temperature cannot be adjusted by pressing ▼ or ▲.

6.5 MODIFYING FAN SPEED

The Ventilation speed (in all operating modes except for dehumidification) of the Indoor unit (or group of indoor units) managed by the wired panel can be modified using the FAN button; every time it is pressed thereafter will switch between one speed and the next (following the sequence indicated below).

Setting the ventilation speed



AUTO	AUTOMATIC Speed
	MINIMUM speed
	LOW speed
	MEDIUM Speed
	HIGH speed
	MAXIMUM speed

Turbo function setting

With the unit on press the "FUNCTION" button to switch to the Turbo function with the "TURBO" icon flashing, then press "ENTER/CANCEL" to start or cancel the Turbo function.

When Turbo function is activated, Turbo function icon " will be bright.

NOTICE



In dehumidification mode, the ventilation speed is low and cannot be adjusted.



If indoor unit's fan speed is set in "Auto", indoor unit will change fan speed automatically according to room temperature in order to make the room temperature more stable and comfortable.

6.6 TIMER SETTING

6.6.1 Modifying the programmed ON/OFF timer - COUNTDOWN mode

To set programmed ON or OFF operations using the countdown mode, perform the following operations:


1. Press the "TIMER" button (if the Indoor unit is ON, the procedure will set a countdown to switch the unit OFF, otherwise the operations will set a time after which the unit will be switched ON); at this stage, the number of hours is shown after which the ON or OFF operation will be performed (next to this number, the wording "HOUR" will begin to flash);
2. Press ▼ or ▲ respectively to decrease or increase the counter by 0.5 hours; press and hold ▼ or ▲ to increase or decrease by 0.5 hours every 0.3 seconds;
3. Press the "TIMER" button again to save the settings; the wording "HOUR" will become steady.

NOTICE



After saving data, pressing the "TIMER" button again will cancel the previous setting. Once the unit is switched ON using a timer function, it will resume the functions and settings in use before the system was switched off for the last time.

Fig. 6.5: Set countdown mode



NOTICE



The system envisages two types of timer management:

- **COUNTDOWN mode** this mode manages programmed unit on-off operations by specifying an "interval" (in hours) after which the unit will switch on or off;
- **CLOCK mode**: this mode manages programmed unit on-off operations by specifying a time when the operations will be performed (in this case, the system clock is activated and displayed).




To set the required management mode, use parameter P33 in the Parameters Menu (for more information, see paragraph "operating parameters"); the default is: "COUNT DOWN".

6.6.2 Set system time (only used in CLOCK mode)

To set the time on the system clock (only used if CLOCK mode is selected in the operating parameters, parameter P33), perform the following operations:

1. Press and hold down the "TIMER" button (5 seconds); at this stage, the symbol  appears will flash to indicate that system time modification mode has been selected;
2. Press ▼ or ▲ respectively to decrease or increase the clock by 1 minute; press and hold ▼ or ▲ for 5 seconds to increase or decrease the time by 10 minutes;
3. Press the "TIMER" button again or the "ENTER/CANCEL" button to save the time and exit the procedure.

Set system time (only used in CLOCK mode)



6.6.3 Set clock mode Modifying the programmed ON/OFF timer

Clock mode is used to manage several functions:

(a) time band management: this function is used to set a switch ON time and a subsequent switch OFF times, thereby defining a time band within which the Indoor unit will operate.

(b) only programmed switch ON: this function is used to set a switch ON time for the unit.

(c) only programmed switch OFF: this function is used to set a switch OFF time for the unit.

To set clock mode functions, perform the following operations:


1. With the unit ON, press the "TIMER" button; at this stage, the working "ON" appears and flashes to indicate the time when the switch ON operation should be performed;
2. Press ▼ or ▲ respectively to decrease or increase the switch on time by 1 minute; press and hold ▼ or ▲ for 5 seconds to increase or decrease the time by 10 minutes;
3. Press the "TIMER" button to save the switch ON time, the wording "ON" remains steady, while the wording "OFF" appears and flashes (to indicate that the switch OFF time must be entered);
4. Press ▼ or ▲ respectively to decrease or increase the switch off time by 1 minute; press and hold ▼ or ▲ for 5 seconds to increase or decrease the time by 10 minutes;
5. Press the "ENTER/CANCEL" button to save the time band settings and exit modify mode.

NOTICE



After completing the entry of a time band, pressing the "TIMER" button again will activate cancel mode; whenever the "TIMER" button is pressed, the system passes from "ON" time to "OFF" time (the time currently selected will flash); after selecting the time to be cancelled, pressing the "ENTER/CANCEL" button will eliminate it.

Fig. 6.7: Set clock mode



NOTICE



To set the various functions described at the beginning of this paragraph identified as (a), (b) and (c), the sequence of operations may be different; there follow the complete sequences for every function:

(a) time band management: (1) + (2) + (3) + (4) + (5)

(b) only programmed switch ON: (1) + (2) + (5)

(c) only programmed switch OFF: (1) + (3) + (4) + (5)



Once the unit is switched ON using a timer function, it will resume the functions and settings in use before the system was switched off for the last time.

6.7 SET DELIVERY FIN (SWING)


To set delivery fin swing (function NOT AVAILABLE on canalised models), simply press the "SWING" button while the unit is on; every time it is pressed thereafter will switch between one function status to another (following the sequence indicated below).

Up & down swing function:

Up & down swing function has two modes: simple swing mode and fixed-angle swing mode. In unit off status, press "SWING" button and "+" button together for 5 seconds to switch between simple swing mode and fixed-angle swing mode. Up & down swing icon "↕" will blink during switching.

1. When simple swing mode is set in unit on status, press "SWING" button to start or stop up & down swing.
2. When fixed-angle swing mode is set in unit on status, press "SWING" button to adjust swing angle circularly as below:

Set delivery fin (swing)



6.8 QUIET FUNCTION SETTING

The system envisages two different types of operation: "QUIET" and "AUTO QUIET", which differ in terms of the logic they use to manage fan speed. To set this function, perform the following operations:

1. Press the "FUNCTION" button until one of the "QUIET" function icons is displayed ; this function directly sets fan speed to minimum, thereby ensuring the least noise possible; or "AUTO QUIET" ; this function manages fan speed in relation to the difference between indoor temperature and the operating setting, in accordance with the following Cooling conditions:

- If the indoor air Temperature is higher than the setting temperature + 2°C, MEDIUM speed will be set;
- If the indoor air Temperature is lower or equal to the setting temperature + 2°C, MINIMUM speed will be set.


Or Heating conditions:

- If the indoor air Temperature is lower than the setting temperature -2°C, MEDIUM speed will be set;
- If the indoor air Temperature is higher than the setting temperature -2°C, MINIMUM speed will be set.

At this stage, the selected icon will begin to flash, indicating that the chosen low noise function mode selected is active.

2. Press buttons  or  respectively to switch from "QUIET" to "AUTO QUIET" function.
3. Press the "ENTER/CANCEL" button again to activate the selected function.

Fig. 6.9: Set QUIET function



NOTICE



To deactivate this function, press the "FUNCTION" button until the function to be cancelled is selected and then press the "ENTER/CANCEL" button.

6.9 ACTIVATING/DEACTIVATING THE NIGHT-TIME COMFORT FUNCTION


The night-time comfort function controls the air conditioner in an optimal way during the night. The following logic is applied:

- **In cooling or dehumidification:** the temperature setpoint is gradually increased to guarantee maximum comfort combined with energy saving;
- **In heating:** the temperature setpoint is gradually decreased to guarantee maximum comfort combined with energy saving.

If the unit is on (except in automatic or ventilation mode), pressing the SLEEP button activates or deactivates the night time health function.

If the function is active the icon  is displayed on the wired panel.

Setting night-time comfort function



NOTICE



The night time health function is deactivated by switching off the unit, and on restarting will not be active; this function can be activated at any time.

6.10 SET THE DISPLAY FUNCTION ON THE INDOOR UNIT

To activate or de-activate illumination of the indoor unit display (obviously except for canalised units), perform the following operations:


1. Press the "FUNCTION" key until the icon for this function appears ; at this stage, the selected icon will begin to flash, thereby indicating that the function has been selected;
2. Press the "ENTER/CANCEL" button again to activate the selected function.

NOTICE



To deactivate this function, press the "FUNCTION" button until the function to be cancelled is selected and then press the "ENTER/CANCEL" button.

Enabling the display on the indoor unit



When no button is used on the wired panel or no signal is received for 20 consecutive seconds:


- If the Lighting function is enabled, the display backlight will be reduced by half.
- If the Lighting function is disabled, the display backlight will be disabled.

6.11 SET THE ENERGY SAVING FUNCTION ACTIVE ON INDOOR UNIT

This mode is available for heat and cool operations (in the first instance a minimum set is defined, while in the latter case a maximum set is defined as the setpoint limits beyond which it will not be possible to operate the machine); to see this function (with the unit ON), perform the following operations:

1. Press the "FUNCTION" key until the Energy Saving icon appears , at this stage, the selected icon will begin to flash; additionally, the wording "MIN" will be displayed when setting energy saving during cooling mode or "MAX" when setting a value during heating mode.
2. Press the buttons  or  to set a maximum or minimum value (in relation to the active operating mode) to be used as the limit for the operating setpoint.
3. Press the "ENTER/CANCEL" button again to activate the selected function.

Fig. 6.13: Set the ENERGY SAVING function active on indoor unit



NOTICE



To deactivate this function, press the "FUNCTION" button until the function to be cancelled is selected and then press the "ENTER/CANCEL" button.

6.12 SET INDOOR UNIT FILTER CLEANING ALARM

This function is used to set a certain number of operating hours after which the unit will send a message requesting that the air filter be pulled out and cleaned (for the filter removal and cleaning procedure, refer to the indoor unit installation manual); to set this function (with the unit ON), perform the following operations:


1. Press the "FUNCTION" key until the Clean Filter icon appears **CLEAN**; at this stage, the selected icon will begin to flash; The wording "set" will also appear with the current value set for the function.
2. Press buttons ▼ or ▲ to set a value for the desired level (to find out the corresponding number of hours associated with each level, refer to the table in the dwgs at the bottom of the page).
3. Press the "ENTER/CANCEL" button again to activate the selected function.

NOTICE



The system indicates that filter cleaning is underway by displaying the relative icon **CLEAN**. To reset the message (and resume hour metering), press the "FUNCTION" button until the CLEAN function is selected in the same way as for the operations described above at point (1) and then press the "ENTER/CANCEL" button.

Fig. 6.15: Set indoor unit FILTER CLEANING alarm



Long period		Medium period		Short period	
SET	Hours	SET	Hours	SET	Hours
10		20	1400	30	100
11	6000	21	1800	31	200
12		22	2200	32	300
13	7000	23	2600	33	400
14		24	3000	34	500
15		25	3400	35	600
16		26		36	700
17		27		37	800
18		28		38	900
19	10000	29		39	1000

NOTICE



If the value 00 is set (default value), this function will be disenabled.

Description on cleaning level: When setting the Filter Clean Reminder Function, timer zone will display 2 digits, of which the former indicates the pollution degree of operating place and the latter indicates the operating time of indoor unit.

There are 4 types of situations:


Pollution level of the environment where the indoor unit is installed	Description of Levels
Turn off Clean reminding	Timer zone shows 00
Light Pollution	The former digit shows 1 while the latter one shows 0, which indicates the accumulating operating time is 5500 hours. Each time the latter digit increases 1, the operating time increases 500 hours. When it reaches 9, it means the operating time is 10000 hours.
Medium Pollution	The former digit shows 2 while the latter one shows 0, which indicates the accumulating operating time is 1400 hours. Each time the latter digit increases 1, the operating time increases 400 hours. When it reaches 9, it means the operating time is 5000 hours.
Heavy Pollution	The former digit shows 3 while the latter one shows 0, which indicates the accumulating operating time is 100 hours. Each time the latter digit increases 1, the operating time increases 100 hours. When it reaches 9, it means the operating time is 1000 hours.

6.13 X-FAN SETTING

This function is used to dry the coil (only during cool and dehumidification modes) if the unit is switched off before reaching the desired setpoint, in order to avoid the formation of mould or bacteria on the coil; to activate or de-activate this function, perform the following operations:

1. Press the "FUNCTION" key until the icon for this function appears ; at this stage, the selected icon will begin to flash, thereby indicating that the function has been selected.
2. Press the "ENTER/CANCEL" button again to activate the selected function.

Set the X-FAN function on indoor unit



NOTICE




To deactivate this function, press the "FUNCTION" button until the function to be cancelled is selected and then press the "ENTER/CANCEL" button.

6.14 SET THE ANTIFREEZE FUNCTION ON INDOOR UNIT

This function (only in Heat mode) allows setting a minimum room temperature; after setting it, the function is activated automatically if the room temperature falls below 6°C and is then deactivated when the temperature rises above 10°C; to activate or de-activate this function, perform the following operations:

1. Press the "FUNCTION" key until the icon for this function appears ; at this stage, the selected icon will begin to flash, thereby indicating that the function has been selected.
2. Press the "ENTER/CANCEL" button again to activate the selected function.

Set the ANTIFREEZE function on indoor unit



NOTICE



To deactivate this function, press the "FUNCTION" button until the function to be cancelled is selected and then press the "ENTER/CANCEL" button.

6.15 SHIELDING STATUS

Remote Shield Function: Remote monitor or central controller can disable the relevant functions of wired controller so as to realize the function of remote control.


When the remote monitor or central controller activates Remote Shield on the wired controller, "SHIELD" icon will show. If user wants to control through the wired controller, "SHIELD" icon will blink to remind that these controls are disabled.

6.16 SET KEY LOCK ON WIRED PANEL

This function is used to lock the buttons of the wired panel connected to the unit; to activate or de-activate this function, perform the following operations:

Press buttons  or  simultaneously for at least 5 seconds. The icon  then appears to indicate button lock activation; on pressing these two buttons again (for a further 5 seconds), the unit is unlocked and the icon  disappears.

Set key lock on wired panel




6.17 INQUIRY OF INDOOR TEMPERATURE WITH ONE BUTTON

In the homepage, hold "ENTER/CANCEL" button for 5 seconds, and the wired controller will display the indoor temperature for 5 seconds.

Within the 5 seconds, it can quit displaying the indoor temperature immediately and be responded to the instructions as usual after pressing any buttons.

7 DISPLAY OPERATING ERRORS OR SYSTEM MESSAGES

These units envisage signals for various alarms, operating errors or system messages using a code shown on the wired panel display (as well as on the indoor unit display for units where this is envisaged); alarm codes and related causes are listed below.



Current alarm code (if there are several simultaneous alarms, the codes will be displayed on rotation)

NOTICE



Reminder: in the event of an alarm, the unit must be switched off and the technical assistance service contacted for any kind of intervention on the unit.

8 TABLE OF DISPLAY ERROR CODES FOR MV UNIT

8.1 TABLE OF ERROR CODES FOR OUTDOOR UNIT

Code	Description
E0	Outdoor unit error
E1	High pressure protection
E2	Low temperature alarm (discharge)
E3	Low pressure protection
E4	Excessive temperature on compressor discharge
Ed	Low Temperature Protection of Driver Module
F0	Outdoor unit electronic card malfunction
F1	High Pressure Sensor Error
F2	Inlet Tube Temperature Sensor Error of Plate Type Heat Exchanger
F3	Low Pressure Sensor Error
F4	Outlet Tube Temperature Sensor Error of Plate Type Heat Exchanger

Code	Description
F5	Temperature sensor error on compressor discharge 1
F6	Temperature sensor error on compressor discharge 2
F7	Temperature sensor error on compressor discharge 3
F8	Temperature sensor error on compressor discharge 4
F9	Temperature sensor error on compressor discharge 5
FA	Temperature sensor error on compressor discharge 6
FC	Compressor power supply current sensor error 2
FL	Compressor power supply current sensor error 3
FE	Compressor power supply current sensor error 4
FF	Compressor power supply current sensor error 5
Fd	Compressor power supply current sensor error 6
FP	Malfunction of DC motor
FU	Temperature sensor error on compressor 1
Fb	Temperature sensor error on compressor 2
Fd	Exchange module outlet tube temperature sensor error
Fn	Exchange module inlet tube temperature sensor error
Fy	Water-in Temperature Sensor Error
J1	Over-current protection on compressor 1
J2	Over-current protection on compressor 2
J3	Over-current protection on compressor 3
J4	Over-current protection on compressor 4
J5	Over-current protection on compressor 5
J6	Over-current protection on compressor 6
J7	4 way valve protection
J8	High pressure protection
J9	Low pressure protection
JA	Abnormal pressure protection
JL	Protection of Water Flow Switch
JL	Protection of Low High-pressure
JE	Oil Return Pipe is Blocked
JF	Oil Return Pipe is Leaking
JJ	Inlet water temperature too low protection
b1	Ambient air temperature probe
b2	Temperature probe 1 error for defrosting
b3	Temperature probe 2 error for defrosting
b4	Under-cooling probe error (fluid leak)
b5	Under-cooling probe error (gas leak)
b6	Error on fluid separator inlet probe
b7	Error on fluid separator outlet probe
b8	Outdoor Humidity Sensor Error
b9	Heat Exchanger Gas-out Temperature Sensor Error
bA	Oil return temperature probe error
bH	System Clock Malfunction
bE	Malfunction of Entry Tube Temperature Sensor of Condenser
bF	Malfunction of Exit Tube Temperature Sensor of Condenser

Code	Description
bJ	High and Low Pressure Sensors are Connected Inversely
bP	Oil return temperature probe error 2
bU	Oil return temperature probe error 3
bb	Oil return temperature probe error 4
bd	Air-in Temperature Sensor Error of Subcooler
bn	Liquid-in Temperature Sensor Error of Subcooler
bY	Water-out Temperature Sensor Error
P0	Compressor Drive Board Error
P1	Inverter compressor control card malfunction
P2	Protection of Compressor Drive Board Power Supply
P3	Protection of Compressor Drive Board Module Reset
H0	Error of Fan Drive Board
H1	Malfunction of Fan Drive Board
H2	Fan power supply module protection
GH	PV DC/DC Protection

8.2 TABLE OF ERROR CODES FOR INDOOR UNIT

Code	Description
L0	Indoor unit error
L1	Fan protection
L2	Electric resistor protection
L3	Water Full Protection
L4	Wired panel power supply error
L5	Anti-freeze protection
L6	Mode conflict
L7	No master set on system
L8	Insufficient power supply
L9	Too many units in the group
LR	Indoor Units Incompatibility Error
LH	Poor air quality warning
LC	Incompatibility between indoor and outdoor units
LF	Shunt Valve Setting Error
LJ	Wrong Setting of Function DIP Switch
LP	Malfunction of PG motor
LU	Inconsistent Branch of Group-controlled Indoor Units in Heat Recovery System
Lb	Inconsistency of Group-controlled Indoor Units in Reheat Dehumidification System
Ld	Indoor fan 2 error
Ln	Lift Panel Return Air Frame Reset Exception
d1	Indoor unit control electric card error
d3	Room air sensor error
d4	Inlet Pipe Temperature Sensor Error
d5	Malfunction of Middle Tube Temperature Sensor
d6	Outlet Pipe Temperature Sensor Error
d7	Humidity probe error
dB	Water Temperature Abnormal
d9	Jumper cap error
dR	Indoor unit addressing error
dH	Connection error between wired panel and Indoor unit control card

Code	Description
dC	DIP switch setting error for selecting size
dL	Outlet air temperature sensor error
dE	Indoor unit CO ₂ sensor error
db	Indicates that Debug mode is active
dn	Swing Assembly Error
dY	Water temperature sensor error
Y1	Inlet Pipe Temperature Sensor 2 Error
Y2	Outlet tube temperature probe 2 error
Y3	Central tube temperature probe 2 error
Y7	-
Y8	Indoor Air Box Sensor Error
Y9	Outdoor Air Box Sensor Error
YR	IFD error
YH	-
YC	Return air inlet temperature sensor error
YL	Air-return Outlet Temperature Sensor Error
YE	High Liquid Level Switch Error
YF	Low Liquid Level Switch Error
o0	Motor drive error
o1	Low Voltage of IDU Bus Bar
o2	High Voltage of IDU Bus Bar
o3	IDU IPM module protection
o4	IDU Startup Failure
o5	IDU Overcurrent Protection
o6	IDU Current Detective Electric Circuit Error
o7	Desynchronizing protection of IDU
o8	IDU Driver Communication Error
o9	Communication Error of IDU Master Controller
oR	High temperature of IDU module
oC	Indoor unit charging circuit error
ob	Temperature sensor error of IDU module

8.3 TABLE OF DEBUGGING CODES

Code	Description
U2	Jumper cap setting error on outdoor unit (capacity selector)
U3	Protection on system power supply phase sequence
U4	Refrigerant low protection
U5	Addressing error on compressor control card
U6	Electronic expansion valve abnormal function alarm
U7	Grid DRED0 Response Protection
U8	Indoor unit refrigerant circuit malfunction
U9	Indoor unit refrigerant circuit malfunction
UR	DC bus over-voltage protection
UH	DC bus under-voltage protection
UC	Master indoor unit is successfully set
UL	Emergency mode (wrong compressor DIP switch settings)
UE	Refrigerant Charging is ineffective
UF	Exchange module indoor unit identification error
UJ	PV module F0 protection
UP	Thermal storage tank module shut-down error protection


Code	Description
Uu	Electronic expansion valve leak error of thermal storage module
Ub	Protection without shutdown error of thermal storage module
Ud	Grid-connection driver board error
Un	Communication error between grid-connection driver board and master controller
UY	PV module overheating protection
U0	Communication error (general)
U1	Communication error of expansion board
U2	Communication error (between master and compressor control card)
U3	Communication error (between master and fan control card)
U4	No communication with indoor unit
U5	Alarm of Indoor Unit Project Number Collision
U6	Alarm of Wrong Number of Outdoor Unit
U7	Communication error on exchange module
UH	Power yield error (excessive power)
U0	Master unit not assigned
UL	Power yield error (low power)
UE	Communication error between the exchange module and the indoor unit
UF	Master error (more than one master has been assigned)
Ud	General address assignment error
UP	Master error (more than one master has been assigned for wired panels)
UU	Communication error (between Indoor unit and remote receiver)
Ub	IP address assignment error
Ud	Communication error between the exchange module and the outdoor unit
Un	Internal and external network error of the exchange module
UY	Communication error of the exchange module

Code	Description
RY	Shielding status
n3	Compulsory defrosting
q5	Setting of ordinary units and high sensible heat units
q7	Select degree Celsius or Fahrenheit
q8	Discharge low temperature protection revision value
q9	Setting of defrosting mode
qL	Setting of static pressure
qE	EVI Operating Mode
qF	System compulsory cooling mode
qP	Unit export area setting PV
qU	Grid voltage system configuration
qb	Anti-condensation temperature setting
qd	Setting of target degree of super-cooling of unit
qn	PV grid-connected settings
qy	Working mode of compressor heating belt

8.4 TABLE OF STATUS CODES


Code	Description
R0	Unit on hold because of debug mode
R1	Compressor operating parameter control procedure underway
R2	Insufficient refrigerant gas quantity warning (replenishment required)
R3	Defrost
R4	Oil return
R5	Unit in test mode
RB	Pump down mode currently underway
R9	Operate in Setback Function
RH	Heating
RE	Cooling
RF	Ventilation
RJ	Indoor unit air filter cleaning warning
RU	System emergency stop (from remote system)
Rb	System emergency stop
Rd	Protected operation
Rn	Lock status

SCARICA L'ULTIMA VERSIONE:




<http://www.aermec.com/qrcode.asp?q=4728>

DOWNLOAD THE LATEST VERSION:



<http://www.aermec.com/qrcode.asp?q=4722>

TÉLÉCHARGER LA DERNIÈRE VERSION:



<http://www.aermec.com/qrcode.asp?q=4726>



Aermec S.p.A.

Via Roma, 996 - 37040 Bevilacqua (VR) - Italia

Tel. +39 0442 633 111 - Fax +39 0442 93577


marketing@aermec.com - www.aermec.com

BITTE LADEN SIE DIE LETZTE VERSION
HERUNTER:



<http://www.aermec.com/qrcode.asp?q=4720>

DESCARGUE LA ÚLTIMA VERSIÓN:



<http://www.aermec.com/qrcode.asp?q=4724>